Part Number: H-NT-7V(E)

Description: Canyon Dual Sport Saddle

Fitment: Honda NT 700V


Revision: 1

Tools Required	Parts List
Phillips Screwdriver	1 Wiring Harness / pigtail2 6" zip ties1 #FACC-05 Small Fuse Adapter
	1 Fuse box rain cover

- 1. Remove your stock seat. Refer to your owner's manual if necessary.
- 2. To install the seat without heater unit. Slip the front tab of your saddle under the front seat mount at the rear of the gas tank, align the rear Corbin bracket to the stock locking mechanism and push down on the saddle until you hear the lock click (*Figure 1*).

Heater Installation:

- 1. If you ordered the heated model, we also included a wiring harness and fuse adapter that hooks into your stock fuse box, so start by connecting the fuse adapter to the wiring harness if it's not done so already (Figure 2).
- 2. Locate the fuse box and remove the 10amp accessory fuse position and insert the fuse into the adapter at the end of the wiring harness (Figure 3).
- 3. Slip the fuse through the hole in the included rain cover, then Insert the adapter into the fuse box into the space previously occupied by the 10 amp accessory fuse (*Figure 4*).
- 4. The fuse box cover won't close because of the fuse adapter, so close the fuse box cover loosely then cover the entire fuse box with the rain cover (Figure 5).



Corbin





- 5. Connect the ground wire to to the negative battery terminal using a Phillips screwdriver (*Figure 6*).
- 6. Bundle loose wiring and secure with included zip ties (*Figure 7*). Do not tighten excessively or you may damage the wiring... just secure it in place for cleanliness.
- 7. Be sure you have left enough wire on the pigtail to reach the seat.
- 8. Plug wire harness into the seat and test. To do this, just plug the harness into the seat (*Figure 6*), turn on your ignition switch and flip the switch on the saddle. If the switch illuminates, the saddle heater is working.
- 9. Proceed with saddle mounting as outlined above.


Enjoy your new saddle!

NOTE: The heater is controlled by the switch along the side the saddle. The temperature is regulated by an internal thermostat when the heater switch is turned on.









Questions? Give us a holler... 800-223-4332 tech@corbin.com