

## Part # 21053

### CB650F 2014> Belly Pan

#### Kit contents:

2x mounting brackets	CFK21053
3x M6 x 16 flange head socket	CBOL0251
3x M6 nylock nut	CNUT0200
3x M6 flat steel washer	CWAS0201
4x M6 black plastic washer	CWAS0221
1X M6 x 30 flange head socket	CBOL2166
1x 20mm black plastic spacer	CSPA012



#### Method:

- Refer to figs 1 and 2 for general layout of brackets. Attach the two brackets as shown – Using original engine bolts – Fully tighten.
- Loosely attach belly pan to these brackets with 3 x M6 x 16 screws, with black plastic washer, flat steel washer and nylock nut.
- The fourth fixing point is into a pre-drilled and taped hole at the bottom right hand side of the bike chassis. Use the M6 x 30 screw and black plastic washer along with the 20mm black plastic spacer provided.
- Now tighten all four mountings checking for even clearance of the belly pan – especially around the exhaust.



Fig 1



Fig 2