Part Number: H-CTX13-E

Description: Dual Touring Saddle

Fitment: Honda CTX 1300

Revision: 1



Tools Required	Parts List

- 1. Remove the stock seat from the motorcycle, refer to your owner's manual if necessary.
- 2. Once the seat is removed, locate the wiring harness on your bike (*Figure 1*).
- 3. Disconnect the plug from the wiring harness (*Figure 2*).

NOTE: You may want to mark the tubes on the plug before you disconnect the plug, to remember which color wire goes into each tube (ex. "R" for Red and "G" for green) *Figure 2*.

4. Plug the wires on the Corbin seat into the tubes on the plug you just disconnected. Red wire goes into the red tube and black goes into the green tube (Figure 3).

NOTE: *Figure 4* shows the angle of how the Corbin wires should go into the tube. Make sure you put the correct wires in each tube because once connected, you need a special tool to remove them.

- 5. Reconnect the plug to the wiring harness (*Figure 5*).
- 6. To install your Dual Touring Saddle, simply slide the saddle into place nose first to engage the tongue, lower the rear into place and push firmly on the passenger platform to latch.

Questions? Give us a holler... 800-223-4332 tech@corbin.com









