



# **CB1100 Genuine Accessory User's Guide**

### FRONT FORK TOP




- When this accessory becomes dirty, rinse it thoroughly with cool water to remove loose dirt. then wipe with a clean cloth or sponge.
- Do not use a brush to clean this accessory as it may scratch the surface.
- Never use organic solvents such as gasoline, thinner, or benzine to clean this accessory. Also do not use acid or alkaline cleaners to clean this
- Wipe up spilled brake at once as it may damage the surface.

#### METER COVER



- When this accessory becomes dirty, rinse it thoroughly with cool water to remove loose dirt. then wipe with a clean cloth or sponge.
- Do not use a brush to clean this accessory as it may scratch the surface.
- Never use organic solvents such as gasoline, thinner, or benzine to clean this accessory. Also do not use acid or alkaline cleaners to clean this
- Wipe up spilled brake fluid at once as it may damage the plastic surface.

# **GRIP HEATER**




- This accessory replaces the throttle pipe with a combined heated grip/throttle pipe. Therefore, the throttle operation has a different feel after installation.
- Use a 5A fuse for replacement of the fuse of this accessory harness. Do not use any other fuse for replacement.

<RIGHT SIDE>




# **METER PANEL**




- When this accessory becomes dirty, rinse it thoroughly with cool water to remove loose dirt, then wipe with a clean cloth or sponge.
- Do not use a brush to clean this accessory as it may scratch the surface.
- Never use organic solvents such as gasoline. thinner, or benzine to clean this accessory. Also do not use acid or alkaline cleaners to clean this accessorv.
- · Wipe up spilled brake fluid at once as it may damage the plastic surface.

### **HEADLIGHT CASE**



- When this accessory becomes dirty, rinse it thoroughly with cool water to remove loose dirt, then wipe with a clean cloth or sponge.
- Do not use a brush to clean this accessory as it may scratch the surface.
- · Never use organic solvents such as gasoline, thinner, or benzine to clean this accessory. Also do not use acid or alkaline cleaners to clean this accessory.
- Wipe up spilled brake fluid at once as it may damage the plastic surface.

### **REAR CARRIER**



• The weight of the cargo must not exceed the following maximum weight capacity:

17.6 lb (8.0 kg)


© 2012 Honda Motor Co., Ltd. MII 14356 (1211)

# CB1100 Genuine Accessory User's Guide

# SIDE COVER




- When this accessory becomes dirty, rinse it thoroughly with cool water to remove loose dirt, then wipe with a clean cloth or sponge.
- Do not use a brush to clean this accessory as it may scratch the surface.
- Never use organic solvents such as gasoline, thinner, or benzine to clean this accessory. Also do not use acid or alkaline cleaners to clean this accessory.
- Wipe up spilled brake or battery fluid at once as it may damage the plastic surface.



2. Position the hinge of the lock assembly on the carrier base as shown.


### **TOP BOX**




- The weight of the cargo must not exceed the following maximum weight capacity:
- 6.6 lb (3.0 kg)
- Be sure that the top box is installed securely before riding.
- The top box is not perfectly watertight, and water may enter when washing the motorcycle or when it rains.

# -EVER HOW TO INSTALL THE TOP BOX


- 1. Insert the retaining tabs of the top box into the carrier base as shown.
  - Install the top box with the handle lever raised.




3. Lower the handle lever as shown.




Lock the top box by turning the key in the direction shown.



# CB1100 Genuine Accessory User's Guide




- 5. Be sure that handle lever cannot be released and the top box is installed securely.
  - The top box may come off while riding unless it is mounted securely.



2. Raise the plate lock and open the lid.


# **HOW TO REMOVE THE TOP BOX**

 Remove the top box in the reverse order of installation.




# **HOW TO CLOSE THE TOP BOX**


1. Close the lid and lower the plate lock.



# **HOW TO OPEN THE TOP BOX**

1. Release the lock by turning the key clockwise.





- 2. Turn the key counter clockwise as shown to lock
  - Confirm that the lid and plate lock are closed securely.

